



**POLARIS**<sup>®</sup>  
*Racing*



**TIP #10 2005 440 IQ and 800 MOD Steering Effort.**

To reduce steering effort, lubricate the upper and lower control arm bearings with WD-40 or equivalent each race day. After lubricating, cover the top of the upper control arm bearing with duct tape to prevent water ingestion.



**Lower Control Arm Bearing**



**Upper Control Arm Bearing**



**Placement of Duct Tape**